


FISKARS®

Tag Maker Punch

197500-1001, 197510-1001, 197560-1001, 197580-1001



Set Eyelet



Questions?

Call Customer Service:
1-866-348-5661

How to punch the shape



1. Insert paper into lower slot.



2. Press to punch tag shape.

How to punch the hole



1. Insert tag into upper slot.



2. Align straight in upper slot.



3. Press to punch tag hole.

How to set the eyelet



1. Assemble eyelet by placing tag hole on post with eyelet on top.



2. Press to set eyelet.



3. Set eyelet will fit snug on tag shape.