

Extendable Pruning Stik® Blade Replacement

9240

Questions?
Call Customer Service:
1-866-348-5661

Required Tools (not included):

- Needle-nose pliers
- Crescent wrench
- Slotted screwdriver

Blade replacement components:

- New blade
- Spring
- Link (2 pcs)



1. Use the needle-nose pliers to remove the end of the spring attached to the blade. Once this is removed from the blade, detach the other end of the spring.



2. Use a slotted screwdriver to pry off the link plate by inserting the tip and twisting back and forth until an end of the link plate snaps off. Once the link plate is off, remove the link that connects the chain and the blade.



3. Next, loosen and remove the pivot bolt using the crescent wrench. Now the blade and bolt can be removed from the pivot housing.



4. Remove the bolt from the old blade and insert it into the new blade. Apply grease or light oil to the backside of the blade around pivot hole as shown for smooth removal.

Questions?
Call Customer Service:
1-866-348-5661



5. Insert the blade and bolt back into the pivot bolt housing. Hand-start the nut and turn until the nut/bolt assembly fits snugly. Tightening can be completed once you are through with assembly.



6. Lay the link plate and link as shown. Note that the recessed areas in the holes are facing up.



7. Insert the link into the hole in the blade and the chain as shown.



8. Hook the bottom of the link plate, rotate it until the link tab can be seen and lined up. Using the needle-nose pliers, snap the link plate into position.



9. If your blade replacement kit came with a clip, it may be inserted as shown.



10. Reattach one end of the spring as shown.

Questions?
Call Customer Service:
1-866-348-5661



11. Use the needle nose pliers to attach the other end of the spring to the blade.



12. Actuate the tool using the orange handle. If the cutting blade will not fully open, use the crescent wrench to loosen the pivot nut/bolt until it does.



When adjusted properly, the black circle on the head will be mostly visible.